CABINET PARTS

For Models: 3ED27DQXBW00
(White)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: 3ED27DQXBW00
(White)

Illus. No.	Part No.	DESCRIPTION
1	489048	Screw
2	2152011	Front Roller (2)
3	489393	Screw,
4	981122	Roller (Rear) (2)
5	488454	Screw
6	2158579	Cover, Terminal Block
7	1129346	Terminal Block
8	1129449	Bushing
9	836196	Shim
10	489211	Screw
11	489346	Screw
12	2155449	Hinge Top (2)
13	1123515	Shim, Hinge Top
14	489284	Screw
15	1129262	Hinge Cover
16	2155321	Hinge Bottom (R.H)
17	2167227	Gasket
19	2155323	Hinge Bottom (L.H)
20	1129868	Spacer, Hinge
21	1110708	Filler, Wrapper
22	2155486	Grille
23	489367	Screw
24	2165297	Wiring Assembly
25	2155013	Clip, Grille
31	2147310	Tap Plate (2)
35	489242	Screw
40	1129332	Service Cord
41	940139	Drain Fitting
42	1108438	Extension Tube
43	1108439	Clip, Drain Tube
47	2167191	Cover, Unit
48		Cabinet (Not A Serviceable Part)
49	1119787	Hinge Cover
52	489348	Clamp, Service Cord
53	489084	Screw
54	2155311	Door Closer, Lower Cam (2)
55	489420	Screw

REFRIGERATOR LINER PARTS

For Models: 3ED27DQXBW00
(White)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	985468	Escutcheon, Meat Pan Control
3	984102	Slide, Meat Pan Control
4	992358	Foam Pad
8	1110718	Stud (6)
11	489290	Screw (2)
13		Track, Shelf
	1114632	Right Side (3)
	1114633	Left Side (3)
14		Track, Shelf
	1115264	Right Side
	1115265	Left Side
16	1124828	Wine Rack
17	1114631	Support, Stud (32)
22	1123919	Bracket Retainer
24	2161251	Air Diffuser Assembly
25	2152019	Air Diffuser Cover
26	2150331	Cover, Conduit
27	486298	Screw
29	851067	Socket
31	2155290	Reservoir
33	851682	Light Bulb
34	1115330	Light Lens
37	488280	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: 3ED27DQXBW00

(White)



Illus. No.	Part No.	DESCRIPTION
1	2162991	Shelf Assembly, Glass Sliding (3)
2	2170578	Snack Bin
3	2162916	Cover, Crisper
4	1115291	Gasket, Crisper (Front)
5	1121385	Gasket, Crisper (Rear)
6	2162845	Trim, Crisper Cover
7	2162983	Glass, Crisper Cover
8	2162790	Cover, Meat Pan
10	2162860	Crisper Pan
11	2162854	Front, Crisper Pan
12	2162849	Slide, Humidity Control
13	489268	Screw (3)
14	2162932	Meat Pan
15	2170522	Egg Bin
16	2164373	Egg Carrier
17	2164374	Cover
18	2162989	Trim
19	2147997	Shelf Stud
20	1115290	Shelf Stud
21	2149540	Shelf Stud
22	1110718	Shelf Stud

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: 3ED27DQXBW00

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: 3ED27DQXBW00
(White)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	1115380	Slide, Ice Door
3	2162946	Door, Ice Compartment
4	2155600	Basket, Small
5	489242	Screw
6	842534	Clip, Air Duct (2)
7	1115317	Support, Stud (4)
9	2162834	Trim, Basket
10	2152088	Basket, Tall
11	2152090	Basket, Slope
12	1106982	Stud, Rear
13	946355	Stud, Support
14	2155572	Wiring Cover
15	489176	Screw
17		Shelf Track
	1126354	Right Side (4)
	1126355	Left Side (4)
18	487042	Screw
19	1115373	Switch, Rocker Arm
20	1110718	Stud (4)
21	1115386	Stud, Shelf (4)
22	2162947	Door, Top Compartment
23	1115256	Shelf, Top Compartment
24	1115389	Light Lens
25	851682	Light Bulb
26	851067	Light Socket
27	946356	Stud, Front
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
31	2155604	Shelf
32	2162939	Trim, Shelf

MOTOR AND ICE CONTAINER PARTS

For Models: 3ED27DQXBW00

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: 3ED27DQXBW00
(White)

Illus. No.	Part No.	DESCRIPTION
1	1118386	Bracket, Motor
2	2165167	Motor, Dispenser
3	2165210	Soleniod Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2149192	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	983663	Coupling, Motor
10	489242	Screw
11	851067	Socket, Light
12	1115339	Cover, Motor
14	2152702	Ice Container
15	983668	Coupling, Conveyor
16	1118480	Stop, Cone
17	1119074	Feeder Cone
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	1119003	Conveyor
28	2171681	Drum
29	1118470	Drive Bar
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
36	1129563	Shield, Wiring
37	2157407	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
41	2152021	Sleeve, Auger
42	2152700	Housing Filler
43	1119043	Deflector, Ice Container
44	2162949	Front Cover, Ice Container
45	851682	Light Bulb
46	983359	Light Lens, Dispenser

REFRIGERATOR DOOR PARTS

For Models: 3ED27DQXBW00

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: 3ED27DQXBW00
(White)

Illus. No.	Part No.	DESCRIPTION
1	2171596	Refrigerator Door (Includes Item 6)
2	2162903	Door, Compartment
3	488500	Screw
4	2170536	Shelf Bin (4)
5	1119373	Insert, Handle
6	2159079	Door Gasket, Magnetic (Repair)
7	1124713	Handle, Center
8	1119359	End Cap, Center Handle
9	935075	Shim
10	1119361	Insert, Handle
11	2155313	Door Closer, Upper Cam
12	489367	Screw
13	2155331	Bracket, Door Stop
14	2163566	Retainer, Bottle
15	1119360	Retainer, Insert (Bottom)
16	1119372	Retainer, Insert
17	2156220	End Cap (2)
18	489075	Screw
19	489022	Screw,
20	2152335	Divider (3)
21	2151653	Hole Plug

FREEZER DOOR PARTS

For Models: 3ED27DQXBW00

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: 3ED27DQXBW00
(White)

Illus. No.	Part No.	DESCRIPTION
1	2170259	Freezer Door (Includes Item 8 And Dispenser Front Parts)
2	1124713	Handle, Center
3	1119359	End Cap (2)
4	488500	Screw
5	935075	Shim, End Cap (2)
6	1123293	Divider, Shelf
7	2170537	Shelf Bin (4)
8	2159078	Door Gasket, Magnetic (Repair)
9	2170920	Trim, Door Shelf
10	489422	Screw
11	2156145	Chute, Ice
12	2155313	Door Closer, Upper Cam
13	489367	Screw
14	2155331	Bracket, Door Stop
15	2156006	Plug, Trim
16	1119360	Retainer, Insert
17	1119373	Insert, Handle
18	1119361	Insert, Handle
19	1119372	Retainer, Insert
20	2156220	End Cap (2)
21	489075	Screw
22	489022	Screw
23	2151653	Hole Plug

DISPENSER FRONT PARTS

For Models: 3ED27DQXBW00

(White)



DISPENSER FRONT PARTS

For Models: 3ED27DQXBW00

(White)

Illus. No.	Part No.	DESCRIPTION
1	1129333	Shroud, Bracket
4		Housing Dispenser (Not A Servicable Item)
5	488687	Screw
6		Tube, Water (See Item #22)
7	2152717	Frame, Slides
8	2152720	Slide, Cube/Crush Switch
9	2167269	Door, Ice
10	2157650	Door Mechanism Assembly
12	1120581	Mechanism Delay
13	1126120	Grille, Overflow
14	987917	Clip, Bearing (2)
15	983697	Bearing, Lever (3)
16	983696	Spring, Lever (2)
17	2147165	Shield, Wiring
18	488500	Screw
19	625834	Spacer, Switch
22	2155020	Water Fitting Assembly (Includes Water Tube)
23	487916	Screw
24	1124718	Lever Assembly, Ice Dispenser
25	1124730	Guide, Ice
26	488892	Screw
27	2152726	Slide, Light Switch
29	2147131	Lamp Holder
31	488361	Screw
32	2147164	Insulator, Control Bracket
33	2147163	Bracket, Control
34	989331	Bulb, Light
35	489101	Screw
36	489155	Screw
37	313125	Switch (3)
38	2159197	Lever Assembly, Water Dispenser
39	2162923	Plaque, Front Cover
40	2162926	Front Cover, Housing (Includes Item 39)
41	2147172	Heat Shield, Frame
42	987049	Bracket, Water
45	489000	Screw
46	2162361	Switch−Water

UNIT PARTS

For Models: 3ED27DQXBW00

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: 3ED27DQXBW00

(White)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	1108179	Fan, Blade
3	2164504	Condenser Assembly
4	489337	Screw
5	2155658	Clip, Wire
6	489019	Screw
7	934011	Clip, Tube (3)
8	2161302	Sleeve
9	2158826	Dampener
10	940073	Clip
11	938384	Strap
12	1108115	Cover
13	2154758	Overload (Includes Relay)
14		Relay (See Overload)
17	2154718	Capacitor
19	509812	Screw Grommet
21	489242	Screw
22	2164519	Evaporator
23	2161324	Clamp
24	2162066	Fan, Motor
25	1110674	Tray, Evaporator
26	2149294	Heat Shield
27	2164409	Drier
28	2154754	Compressor (Includes Items 11, 12, 13, 14 & 17) (Also Order 876765 Tube Kit)
29	488687	Screw
30	2157396	Unit Mounting Frame
31	2167065	Unit, Harness
32	2162062	Fan, Motor Bracket
33	2162214	Heater, Defrost
34	2161330	Clip
35	2161331	Bi−Metal, Defrost
37	489373	Screw
39	1100826	Grommet (4)
40	489340	Screw
41	2149128	Air Baffle
42	2155547	Clip, Heat Shield
43	2161363	Cover Unit, Bottom
44	489396	Clip
48	1127906	Unit Mounting Rail
49	488624	Screw
50	1110663	Guard, Fan
53	489339	Screw
54	227991	Wire Connector
55	488649	Screw
59	983659	Spring−Tube
63	2150347	Union

Following Parts Not Illustrated and Optional Parts Not Included

Part No.	DESCRIPTION
978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

6.5 oz.

AIR FLOW PARTS

For Models: 3ED27DQXBW00

(White)



Illus. No.	Part No.	DESCRIPTION
1	2155594	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
4	489176	Screw
5	2155575	Air Duct Freezer
7	2154976	Fan Motor
8	2169142	Fan Blade
10	2155589	Fan Grommet (2)
11	1115381	Duct, Icemaker
12	2158782	Harness, Fan Evaporator, And Heater, Bi−Metal
13	2155789	Gasket Cover
14	2165001	Wire Tie
16	2155782	Gasket
17	2155612	Cover, Evaporator
18	489355	Screw
21	489242	Screw
22	2155765	Support, R.S
23	2155766	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: 3ED27DQXBW00

(White)



Illus. No.	Part No.	DESCRIPTION
1	2169147	Control Box
2	1110629	Mounting Bracket
3	489397	Screw (2)
4	2149705	Light Switch
6	2162057	Defrost Timer
7	489398	Screw (2)
8	940014	Hole Plug
9	2161284	Thermostat Assembly
10	487869	Screw
11	2161250	Cam Assembly
12	1110560	Bearing Body
13	489242	Screw
14	938439	Retainer, Damper
15	1110559	Pivot Arm
16	627068	Screw
17	1129370	Light Socket
18	1115241	Thermostat, Barrier
19	851682	Light Bulb
20	2149186	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push−On
25	2161213	Escutcheon, Control Box
26	1116852	Thermostat knob
27	1116853	Knob, Air Control
28	837444	Retainer, Knob
29	489203	Spring Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: 3ED27DQXBW00

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: 3ED27DQXBW00 (White)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	836489	Fitting, Water Tube
3	488878	Clamp, Tube
4	841707	Insert, Tube
5	628379	Clip, Fuse
6	489115	Clip
7	2155294	Tube, Water
8	1106508	Seal, Gasket
9	489242	Screw
10	2165238	Valve, Solenoid
11	627018	Nut, Compression
13	2155247	Tube, Water Inlet
14	628337	Washer
15	627860	Tube, Inlet Valve
16	510716	Clamp
17	537588	Nut Valve
18	628329	Cover
19	488649	Screw
20	628282	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
29	628377	Module Assembly
30	489276	Screw
31	2171593	Shut Off Arm
32	628281	Harness, Wiring
33	628320	Bracket
35	628367	Module Assembly (Includes Items 29, 37 & 38)
37	628303	Motor
38	489136	Screw
39	488208	Screw
40	1129179	Nut, Compression
42	488886	Screw
43	1129177	Insert

PARTS NOT ILLUSTRATED

For Models: 3ED27DQXBW00
(White)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350941	Leveler, Enamel (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up Kit (Black)

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	515393	Transformer (115−230 Volts)

LITERATURE PARTS

	LIT2170269	Use & Care Guide
	LIT2167329	Service & Wiring Sheet
	LIT628371	Modular Icemaker Service Sheet

TORX SCREW WRENCH

	1117510	Torx Key

ICE CRUSHER ASSEMBLY
PART NO. 2149072

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST